



Normally gloves are wired in Parallel.  
The Rough Stripe wires are soldered together  
and the Smooth wires are soldered together.



But for Wider Gloves that are wired in Series  
the Rough Stripe wire from one glove is soldered  
to the Rough Stripe wire on the Glove power wire  
and the Smooth wire from the other Glove wire is  
soldered to the Smooth wire on the Glove power wire.  
The left over Rough Stripe and Smooth wires from the  
2 glove wires are soldered together. So when the Gloves  
are plugged in, you have a giant loop.